

Articulated Connector for Flies

1. Cut a piece of #10 wire 3" long
2. Place the wire in the jig next to the large post about $\frac{3}{4}$ "
3. Bend the wire away from the post.
4. Bring the remaining wire around to form a loop.
5. Bend the long leg of the loop to form against the pin to form the rest of the loop.
6. With loop portion of the wire vertical between the fingers, place the end in the jig between the small post and the next smallest post $\frac{3}{4}$ ". (The small right side post)
7. Bend the short piece of wire away from the post.
8. Form the loop as you did the large one.

You should have a small and large loop on each end, one vertical from the other.

When tying the connector the large loop is the one that the dressed hook will go.

